Since 1968



User Manual

COLOR VIDEO DOOR PHONE CDV-70A, 70AM, 70AD, 70AMD



www.commax.com

COMMAX Co.,Ltd.

- соммах
- Thank you for purchasing COMMAX products.
- Please carefully read this User's Guide (in particular, precautions for safety) before using a product and follow instructions to use a product exactly.
- The company is not responsible for any safety accidents caused by abnormal operation of the product.

Table of Contents

| 1. Product Overview | 4 |
|---------------------------------|----|
| 2. Operation Methods | 5 |
| 3. Save visitor's image & setup | 7 |
| 4. Installation and wiring | 10 |
| 5. Components | 11 |
| 6. Specification | 12 |

Note : The function of "Save visitor" image & setup"(page 7) is available for CDV- 70AM/CDV- 70AMD only. CDV-70A/CDV-70AD doesn't feature to save visitor's image.

Warnings and caution

◎ Make sure to follow the instructions to prevent any danger or property losses.



Downloaded from www.Manualslib.com manuals search engine

COMMAX Co., Ltd.

2

Warnings and caution









| No. | Description | No. | Description | No. | Description |
|-----|--|-----|----------------------------------|-----|--|
| 1 | Speaker | 7 | Door Release button | 13 | Screen resolution Button |
| 2 | On/Off & display LED | 8 | MIC | 14 | Screen resolution Button |
| 3 | Monitoring button(Record images) | 9 | Volume control button | 15 | On/Off switch |
| 4 | Interphone button | 10 | Callingsoundlevel control button | 16 | DC power terminal |
| 5 | Talk button | 11 | Screen resolution Button | 17 | -Terminal for connecting camera and interphone |
| 6 | Priority button(PTT) or Menu for Recording | 12 | Screen resolution Button | | -DIP switch for camerasetting |

* DC Power terminal(Non polarily) : 17-30V == (only CDV-70AD/CDV-70AMD)

- * Volume control button: It is to adjust talking volume from counter side.
- * Calling sound level control button: It is to adjust calling sound
- * Screen resolution Button: It is to adjust image resolution.
- * DIP switch for camera setting: It is to set up the availability of door camera. Please place it "up" position while door camera is in use.

Note : camera 1, 2 is set to use from manufacturer as default.



How to operate

Receiving a calling from visitor

1. When the call button is pressed by a visitor on the door camera, the melody shall be rung and visitors' image is shown on the screen.

2. Press "talk" button(

(Maximum 60 seconds is available to talk on the phone.)

- 4. Press "door release" button (-) to open the door while on the conversation.

Communication with a interphone

1. Press "Interphone" button (
) to make a conversation with the interphone connected with monitor. (DP-4VHP)

(It is available to talk on the phone for Maximum 60 seconds)

- 2. When receiving a call from an interphone, electrical sound shall be rung. Press "talk" button (
- 3. When you receive a call from camera while taking with interphone, Visitor's image should be showed on the monitor.

It shall be possible to talk between each unit, monitor, interphone and camera.

Note : When you finish talking with visitor or interphone, press "talk" button again to close the talk mode.

Monitoring.

- 1. When you press monitor button ($\bigcirc_{REC.}$), outside image is showed for 30 seconds.
- 2. It can be connected up to 2 cameras and shows you the outside image from camera1 or camera2 in order by pressing " monitoring" button.

- Priority talk PTT (^O_{MENU} P[≫]) When there is impeding noise that disturbs conversation from the door camera, pressing and holding the "PTT" button will deliver only the voice of the speaker from the CDV-70A,70AM / CDV-70AD,70AMD to the door camera unit to help clarify speech.
- Adjustment of image resolution

To adjust brightness or color resolution, use the buttons on the right side.

- ① Press "MENU" button to enter "control menu" in taking with a door camera unit or monitoring status and then push the "SELECT" button.
- ② Scroll the proper menu you want to change by using "UP/DOWN" button. And then push "select" button to enter into "changing mode".
- ③ Press " UP/DOWN" button to change into proper level

| | | | MENU | | |
|----|--------|-------------|------------|-----|----|
| Ut | tility | Contrast | | | 50 |
| | | Brightness | | | 50 |
| | | COLOR | | | 50 |
| | | Sharpness | | | 0 |
| | | | | | |
| | | | | | |
| | | | | | |
| | E | Exit : Menu | Move : 🔺 🔻 | Sel | |

- ④ Press "SELECT" button to save the new one and it return "basic menu" automatically. Adjust each menu as per same way.
- To adjust the ratio of monitor image size, select the "Disp. Ratio" menu and press "SELECT" button.

Press the "UP/DOWN" button to change the ratio of monitor image size.

Setting the Zoom mode allows you to view the object much closer in its original proportion

| | | MENU | | |
|---------|-------------|----------|-----|----|
| Utility | Disp. Ratio | Wide | | 50 |
| | Language | English | | 50 |
| | Reset | • | | 50 |
| | | | | 0 |
| | | | | |
| | | | | |
| | | | | |
| | Exit : Menu | Move∶▲ ▼ | Sel | |

"menu" button shall be pressed to return standby mode from "basic menu" after setting proper level .

Note : "MENU" Button - Enter or Close adjustment mode

"SELECT" button – Select sub - menu or move previous menu "UP/DOWN" button – Scroll the menu or change the value In case if Display Ratio menu of CDV-70AM and CDV-70AMD is set for Zoom Mode, and recording time information may not be reflected correctly. In this case, please, change settings to 'Wide Mode" or 3:4 mode.

COMMAX

6

3. Recording visitors' image and setup.

NOTE : Following function of "Recording visitors' image & setup" is available for CDV- 70AM / CDV-70AMD only. For CDV-70A / CDV-70AD it is not available one.

3-1. Recording visitors' image

Press and hold the "monitoring" button (REC) for 1 second under "talk" or "monitor" mode to save a cut of image with electric sound.

3-2. Review recorded images and its setup

Press and hold the "PTT" button for 2 seconds under stand-by mode, the menu is shown as follows.



Main menu

This above picture is main menu, it shall be able to set up each subject. Description of the above pictures.

A parts : Operation button

B Part : Sub Menu

Note : EXIT - Escape UP/DN - Up & down SEL - Select

3-2-1 Review recorded images and its setting.

Press "review" button to see recorded images . Operation button is same as right side as following picture.



Review



7

In case of that there is no image recorded, "No Image" appears on the screen. Area "A" on above-picture, there are operation button. Press "Del" button to remove the image displayed.

Note : PREV – Previous menu UP/DN - Move the cursor up and down DEL - Remove the image.

* When you press and hold "UP or DOWN" button for 1 second, move 10 cuts.

3-2-2 Delete All Image

Select "Delete all images" menu, to remove all recorded images at one time.



When you select "Yes", following message is shown.

| Menu | PREV |
|----------------|------|
| | SEL |
| Delete Success | UP |
| | DN |
| | |

Delete Image

Then, press "SEL/PREV" button on the right to move previous menu.

Select "Auto Record Setting" menu to automatically save visitors' images while you are away.



Auto record setting

Note : It shall be set as a "Auto Record" mode from manufacturer.

When the visitors call, every visitor automatically is recorded 1 by 1.

Maximum 128 cuts can be saved.

In case 129th cuts is recorded after 128th cuts, it should be replaced from existing 1st cuts (1/128) again.

3-2-4 Time Setting

Select "Time setting" menu to set the time and date.



Time Setting

- 1) When you enter "time setting" mode, year ("2000") shall be flickered.
- 2) Press "SEL" button to active and it turn in red and change current year by using "UP/DN" button.
- 3) When you press "SEL" button again, updated data shall be saved and turn inactive mode in black. Then, move to next menu using UP/DN button.



1) Installation diagram



- Terminal wiring in rear

2) Wiring diagram



CDV-70A / CDV-70AM















M3 X 6 Monitor Fixing Screw



Connector (4PX3 EA)



Power supply(17V 1.3A) (Only CDV-70AD / CDV-70AMD)





| Model Spec. | CDV-70A/70AM |
|----------------------------|---|
| Wiring | CAMERA : 4 wires, INTERPHONE : 4 wires |
| Power source | 100-240V~, 50/60Hz (FREE VOLTAGE) |
| Power consumption | MAX : 15W, Stand-by : 4W |
| Image recording (CDV-70AM) | MAX 128 Cuts |
| Communication way | HANDS FREE type (Voice Switch) |
| Display | 17.78Cm(7") COLOR TFT-LCD |
| Call sound | COMMAX chime : 2 times Interphone : Electric chime |
| Video duration time | Stand-by : 30 seconds, On the line : 60 seconds |
| Distance | Entrance: 50m (Ø0.65) Interphone: 20m (Ø0.65) |

| Model Spec. | CDV-70AD/70AMD |
|----------------------------|---|
| Wiring | CAMERA : 4 wires, INTERPHONE : 4 wires |
| Power source | 17~30V =, 1A |
| Power consumption | MAX : 14.2W, Stand-by:4W |
| Image recording (CDV-70AM) | MAX 128 Cuts |
| Communication way | HANDS FREE type (Voice Switch) |
| Display | 17.78Cm(7") COLOR TFT-LCD |
| Call sound | COMMAX chime : 2 times Interphone : Electric chime |
| Video duration time | Stand-by :30 seconds, On the line : 60 seconds |
| Distance | Entrance: 50m (Ø 0.65) Interphone: 20m (Ø 0.65) |



COMMAX Co.,Ltd.

513-11, Sangdaewon-dong, Jungwon-gu, Seongnam-si, Gyeonggi-do, Korea Int'l Business Dept. Tel. : +82-31-7393-540~550 Fax. : +82-31-745-2133 Web site : www.commax.com *PM0770A00011*

Printed In Korea / 2013.11.104